Do More

Nighthawk X6
AC3200 Tri-Band WiFi Router

Model R8000



NETGEAR®

WiFi Network Name and Password

The preassigned WiFi network name (SSID) and password (network key) are unique to your router, like a serial number. Because the router automatically uses WiFi security, you don't need to set it up. The WiFi settings are on the label on the router.



We recommend that you use the preassigned WiFi settings because you can check the label if you forget them. You can also log in to the router to change these settings. If you do so, write down the new WiFi settings and store them in a safe place.

You can write the WiFi settings from the label on your router in this space for easy reference. If you change the WiFi settings, write the new settings here for easy reference and store this booklet in a safe place.

WiFi network name (SSID):	
Network key (password):	

Join the WiFi Network

You can either use Wi-Fi Protected Setup (WPS) or select your router's WiFi network and type its password.

Join the WiFi Network Using WPS

For help with the **WPS** button on your computer or WiFi device, check the instructions or online help that came with that computer or device. Some older equipment cannot use WPS.

To join the network using WPS:

- Press the WPS button on the router for three to five seconds.
 The WPS LED on the router blinks.
- Within two minutes, on your computer or other WiFi device, press its WPS button or click its onscreen WPS button.
 - The WPS LED on the router lights solid white when the computer or WiFi device connects to your router.
- 3. Repeat this process to add other computers or WiFi devices.

Join the WiFi Network Using the Router's WiFi Settings

Use the router's WiFi network name and password to connect your computer or WiFi device to the router's network through WiFi. If you did not change the router's WiFi network name and password, use the router's preassigned WiFi network name and password, which are on the label on the router

To select your network and enter its password:

- On your computer or other WiFi device, open the WiFi connection manager that manages your WiFi connections.
 - The WiFi connection manager scans for WiFi networks in your area.
- 2. Find and select your router's WiFi network name (SSID). The SSID is on the label on the router.
- Enter the router's password (or your custom password if you changed it) and click the **Connect** button.
 The password is on the label on the router.
 - The password is on the laber on the router.
- 4. Repeat Step 1 through Step 3 to add other computers or WiFi devices.

View or Change the Router Settings

After you use the NETGEAR installation assistant to set up the router, you can log in to the router to view or change its settings.

Log In to the Router

To log in to the router:

- Connect a computer or WiFi device to the router.
 You can connect using a wired connection or a WiFi connection:
 - To connect using a wired connection, use an Ethernet cable (not included) to connect an Ethernet port on your computer to an Ethernet port on the router.
 - To connect using a WiFi connection, find the router's preassigned WiFi network name and password on the label on the router.
 Open the WiFi connection manager on your computer or WiFi device, find the router's WiFi network name, and use the router's password to connect.
- 2. Launch a web browser and visit www.routerlogin.net. A login window opens.
- Enter admin for the user name and password for the password.
 The BASIC Home page displays.

Change the WiFi Network Name and Password

The router's preset WiFi network name (SSID) and password are on the label on the router. If you want to change your router's WiFi network name and password, log in to the router.

To change the router's WiFi network name and password:

- Launch a web browser from a computer or WiFi device that is connected to the network and visit www.routerlogin.net.
 A login window opens.
- 2. Enter the router user name and password.

The user name is **admin** and the default password is **password**. Use the default credentials if you did not change them.

The BASIC Home page displays.

3. Select Wireless.

The Wireless Setup page displays.

- 4. To change the WiFi network name (SSID), enter a new name in the **Name (SSID)** field.
- To change the WiFi password, enter a new password in the Password (Network Key) field.
- Click the **Apply** button. Your settings are saved.

Change the admin Password

To change the admin password:

- Launch a web browser from a computer or WiFi device that is connected to the network and visit www.routerlogin.net.
 A login window opens.
- Enter admin for the user name and password for the password.
 The BASIC Home page displays.
- Select ADVANCED > Administration > Set Password.
 The Set Password page displays.
- 4. Type your old password and type the new password twice.
- To be able to recover the password, select the Enable Password Recovery check box.
 We recommend that you enable password recovery.
- 6. Select two security questions and provide answers to them.
- Click the **Apply** button. Your settings are saved.

Recover a Forgotten admin Password

The default password for the admin user name is **password**. If you changed the password and enabled the password recovery feature, you can retrieve this password.

To retrieve a forgotten admin password:

- Launch a web browser from a computer or WiFi device that is connected to the network and visit www.routerlogin.net.
 A login window opens.
- Click the Cancel button.
 If password recovery is enabled, you are prompted to enter the serial number of the router. The serial number is on the label on the router.
- 3. Enter the serial number of the router.
- Click the **Continue** button.
 A page displays requesting the answers to your security questions.
- 5. Enter the saved answers to your security questions.
- Click the **Continue** button.
 A page displays your recovered password.
- Click the **Login again** button. A login window opens.
- 8. With your recovered password, log in to the router.

Access a USB Device on the Network

ReadySHARE lets you access and share a USB storage device connected to the router's USB ports. (If your USB device uses special drivers, it is not compatible.)



- To access the USB storage device from a Windows computer:
- Connect your USB storage device to a USB port on the router.
 To get the best USB device access speed, use the blue USB 3.0 port on the router. It might take up to two minutes before the USB storage device is ready for sharing.
- On a Windows computer that is connected to the network, select
 Start > Run, enter \\readyshare in the dialog box, and click the OK button.

A window displays the files and folders on the device.

To access the USB storage device from a Mac:

- Connect your USB storage device to a USB port on the router.
 To get the best USB device access speed, use the blue USB 3.0 port on the router. It might take up to two minutes before the USB storage device is ready for sharing.
- On a Mac that is connected to the network, launch Finder and select Go > Connect to Server.

The Connect to server window opens.

- Enter the smb://readyshare in the Server Address field and click the Connect button.
- 4. When prompted, select the **Guest** radio button.
- 5. If you set up access control on the router and you allowed your Mac to access the network, select the **Registered User** radio button and enter **admin** for the name and **password** for the password.

For more information about access control, see the user manual, which is available online at *downloadcenter.netgear.com* or through a link in the router's user interface.

6. Click the **Connect** button.

A window displays the files and folders on the device.

Enable Dynamic Quality of Service

Dynamic Quality of Service (QoS) resolves Internet traffic congestion when Internet bandwidth is limited by using better application and device identification, bandwidth allocation, and traffic prioritization techniques. If you like gaming and streaming videos, then you can benefit from enabling Dynamic QoS.

Note: If you use a gigabit Internet connection, or your Internet download and upload speed is 300 Mbps or faster, then you don't need to use Dynamic QoS.

To enable Dynamic QoS:

- Launch a web browser from a computer or WiFi device that is connected to the network and visit www.routerlogin.net.
 A login window opens.
- Enter the router user name and password.
 The user name is admin and the default password is password. Use the default credentials if you did not change them.
 The BASIC Home page displays.
- Select **Dynamic QoS**.
 The Dynamic QoS page displays.

- 4. Select the **Enable Dynamic QoS** check box.
- 5. Specify your Internet bandwidth.

You can use Speedtest to detect your Internet bandwidth or you can enter your Internet bandwidth manually. We recommend that you use Speedtest.

To use Speedtest to detect your Internet bandwidth, do the following:

- a. For more accurate Speedtest results, make sure that no other devices are accessing the Internet.
- b. Click the **Speedtest** button.
 Speedtest determines your Internet bandwidth.
- Click the **Apply** button. Your settings are saved.
- 7. To view bandwidth utilization by device and application, click the **Click** here to see bandwidth utilization by device and application link at the bottom of the page.

For more information, see the user manual, which is available online at *downloadcenter.netgear.com* or through a link in the router's user interface.

Remotely Access Your Router Using the genie App

You can use the genie app to remotely access your router and change its key settings. Remote access with the genie app is supported for Windows computers, iOS mobile devices, and Android mobile devices. For more information about this feature, see the genie app user manual, which is available online at *downloadcenter.netgear.com*.

To set up remote access using the genie app for Windows computers:

- 1. Visit www.NETGEAR.com/genie and download the latest version of the genie app for Windows.
- 2. Create a remote access genie account:
 - a. Connect your computer to the router's network.
 - b. Launch the genie app.
 - c. Select **Router Settings**.The Router Login page displays.
 - d. From the **Login as** menu, select **Remote Access**.
 - e. Click the **Sign up** link.
 - f. Complete the fields to create an account.

3. Log in to your remote access genie account.

The genie app determines if the router is registered with your genie account. If the router is not registered, follow the onscreen instructions.

After the router registers with your genie account, a cloud icon displays on the page. You can now remotely access your router from the genie app that is installed on your computer.

Remotely Access Your Router With ReadyCLOUD

ReadyCLOUD allows you to remotely access files on a USB storage device connected to the router. For more information about using ReadyCLOUD, see the ReadyCLOUD user manual for routers, which is available online at downloadcenter.netgear.com.

To set up your ReadyCLOUD account and register your router:

- 1. Create a ReadyCLOUD account:
 - a. Visit *readycloud.netgear.com* and click the **Sign In** link. The Sign In page displays.
 - Click the Create Account link, complete the fields to set up your account, and click the Create button.

- 2. Set up and register your router:
 - a. Connect a USB storage device to a USB port on your router.
 - b. Launch a web browser from a computer or WiFi device that is connected to the network and visit www.routerlogin.net. The BASIC Home page displays.
 - c. Select **ReadySHARE**.The USB Storage (Basic Settings) page displays.
 - d. Select the **ReadyCLOUD** radio button. The ReadyCLOUD page displays.
 - e. Enter your ReadyCLOUD user name and password and click the **Register** button.

 The router is now registered with your ReadyCLOUD account.
- 3. After registration, visit *readycloud.netgear.com* and use your ReadyCLOUD user name and password to sign in to your account.

 The ReadyCLOUD page displays the router that you registered and the

contents of the USB storage device that is connected to the router.

Back Up With ReadySHARE Vault

Your router comes with free backup software for all the Windows computers in your home. Connect a USB hard disk drive (HDD) to the USB port on your router for centralized, continuous, and automatic backup.

Note: The following operating systems support ReadySHARE Vault: Windows XP SP3, Windows 7, Windows 8, Windows 8.1, and Windows 10

To back up your Windows computer:

- 1. Connect a USB HDD to a USB port on the router.
- 2. Download ReadySHARE Vault from *netgear.com/readyshare* and install it on each Windows computer.
- Launch ReadySHARE Vault.
 The ReadySHARE Vault dashboard displays.
- Use the dashboard or the **Backup** tab to set up and run your backup jobs.

Print Wirelessly With ReadySHARE Printer

ReadySHARE Printer lets you connect a USB printer to a USB port on the router and print wirelessly.

To set up ReadySHARE Printer:

- Connect the USB printer to a USB port on the router with a USB printer cable.
- 2. On each computer that will share the printer, do the following:
 - a. Install the current USB printer driver software (available from the printer manufacturer).
 - Download the NETGEAR USB Control Center utility from netgear.com/readyshare and install it.
 - c. Select the language.
- If prompted, select the printer and click the Connect button for each computer.

When the first computer connects, the status changes to Manually connected by xxx.

For each computer, when you complete Step 3, the printer status displays as Available.

More Premium Features

Your router lets you do the following and more:

- Play music from a USB storage device with iTunes server.
- Set up a secure VPN service connection to your home network.
- Create a personal FTP server with a custom URL.

iTunes Server

iTunes server lets you play music with iTunes on your Windows or Mac computer or with the Apple Remote app on your iPhone or iPad from a USB storage device that is connected to a USB port on your router. You can also use the Apple Remote app from an iPhone or iPad to play music on any AirPlay devices, such as Apple TV or AirPlay-supported receivers.

To set up the router's iTunes server to play music on your Windows or Mac computer, you must set up Home Sharing.

To set up the router's iTunes server to play music on your iPhone or iPad, you must download the Apple Remote app.

For more information about how to set up iTunes server, see the user manual, which is available online at *downloadcenter.netgear.com* or through a link in the router's user interface.

VPN Service

VPN service allows remote access to your home network with a secure connection. After you set up VPN service, you can use VPN to access the router's USB drive and media and to access your Internet service at home.

For more information about how to set up VPN service, see the user manual, which is available online at *downloadcenter.netgear.com* or through a link in the router's user interface.

Personal FTP Server

With your customized free URL, you can use FTP to access your network when you aren't home through Dynamic DNS.

For more information about how to set up your FTP server, see the user manual, which is available online at *downloadcenter.netgear.com* or through a link in the router's user interface.

Support

Thank you for purchasing this NETGEAR product. You can visit www.netgear.com/support to register your product, get help, access the latest downloads and user manuals, and join our community. We recommend that you use only official NETGEAR support resources.

Trademarks

© NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

Compliance

For the current EU Declaration of Conformity, visit http://support.netgear.com/app/answers/detail/a_id/11621/.

For regulatory compliance information, visit http://www.netgear.com/about/regulatory/.

See the regulatory compliance document before connecting the power supply.

201-20124-01

February 2016

NETGEAR, Inc.

350 East Plumeria Drive San Jose, CA 95134, USA